

Instruction manual



**Universal mobile Diagnosis Measurement System
for Service, Development and Quality Control**

▪ 1. Table of contents

1. Table of contents	2
2. Read first	4
2.1 General safety notes	4
2.1.1 Operating instructions	4
2.1.2 Safety notes	4
2.1.3 Water and moisture	4
2.1.4 Ventilation	4
2.1.5 Effect of heat	4
2.1.6 Electrical connection	5
2.1.7 Protection of current and measuring lines	5
2.1.8 Cleaning	5
2.1.9 Devices not being used or in storage	5
2.1.10 Entry of foreign objects	5
2.1.11 Service and maintenance in the event of damage	5
2.2 Information of disposal	5
3. Basic operation	6
3.1 Switch on	6
3.2 Brightness of display	6
3.3 Beeper	6
3.4 Status line	6
3.5 Selection of the measuring display	7
3.6 Reset of peak values	7
3.7 Display hold	8
3.8 Methods of input	8
3.9 Switch off	8
4. Setting sensor parameters	9
4.1 Setting sensor parameters manually	9
4.2 Setting sensor parameters by chip identification	10
5. System settings	11
6. Zero point correction	12

7. Memory functions	14
7.1 Record a measurement.	15
7.1.1 Automatic triggering	15
7.1.2 Manual triggering	15
7.1.3 Recording time.	16
7.1.4 Short description of a recording.	16
7.1.5 Initiate a recording	17
7.1.6 Start the recording.	19
7.1.7 Stop the recording.	19
7.2 Invoke stored recordings.	20
8. Status key, show device information	23
9. Info key, show all sensor information	24
10. Battery indicator	24
11. Scanning a Sensor with identification chip	25
12. Configuration of measuring displays	26
12.1 Delete measuring windows	27
12.2 Set measuring windows	28
12.3 Configure measuring windows.	29
13. Colour profiles	32
14. Error messages	34
15. Reset the device	35
16. Firmware update	37
17. Technical Specifications	39

▪ 2. Read first

▪ 2.1 General safety notices for electrical equipment

The set up, start up and maintenance of electrical devices should always be performed by trained, qualified personnel! To avoid the danger of electrical shock, the device housing must not be opened or removed. The inside of this device contains parts that should only be serviced or operated by trained, qualified personnel. There are no user-serviceable parts inside. To prevent short circuits or danger of electric shock, these devices must not be exposed to high humidity or moisture. The symbol showing a lightning bolt with an arrowhead pointing downward and contained within an equilateral triangle indicates that the device contains uninsulated parts standing under high voltage. Contact with these parts may result in a harmful or fatal electrical shock.

▪ 2.1.1 Operating instructions

Read the data sheet, operating instructions, safety guidelines and, if necessary, the certificate of conformity before placing the device in operation for the first time. Be sure to retain the documentation and store it in a place where it can be readily accessed for further reference.

▪ 2.1.2 Safety notes

For your own benefit, be sure to read all warning notes on the device and in the related documentation mentioned above. Be sure to comply with all regulations pertaining to the use and operation of this device. Do not, under any circumstances, open a device in cases where this is expressly prohibited.

▪ 2.1.3 Water and moisture

Never use this device in moist, humid environments or near water. Be sure to note the protection type specified in the data sheet.

▪ 2.1.4 Ventilation

This device should always be used in locations with adequate ventilation. Any opening on the device must remain free and unobstructed to ensure proper ventilation. Avoid placing the device on surfaces that could accumulate static charge.

▪ 2.1.5 Effects of heat

Note any maximum operating temperature specified in the data sheets. Avoid placing the device near sources of heat.

UC 660 Mobil Version 1.6.x

- 2.1.6 Electrical connection

Connect the device only as shown in the wiring diagram, data sheet and/or operating instruction.

- 2.1.7 Protection of current and measuring lines

The device leads should be routed so that they cannot be tripped over or stepped on and so that nothing can be placed on or against them. In this regard, pay particular attention to the sections of leads near plugs, power sources and where they connect to the device.

- 2.1.8 Cleaning

Do not use any strong cleaning agents. When cleaning the device, be sure that fluid does not enter the interior.

- 2.1.9 Devices not being used or in storage

If the device will not be used for an extended period of time, be sure to disconnect the power supply.

- 2.1.10 Entry of foreign objects

Be particularly careful to ensure that neither fluids nor foreign objects can enter and contaminate the interior of the device.

- 2.1.11 Service and maintenance in the event of damage

This device must only be serviced by trained, qualified personnel. In doubtful cases, "Unit Control Messtechnik" should always be consulted. Repairs performed without proper advice and consultation can have serious, dangerous consequences and may even void the right to claim under device warranty.

- 2.2 Information on Disposal

For business users in the European Union:

If you wish to discard electrical and electronic equipment, please contact your local dealer or supplier for further information.

Information on disposal in other countries outside the European Union:


The disposal symbols are only valid in the European Union . If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.

▪ 3. Basic operation



▪ 3.1 Switch on

Switch on the device with **ON** .

After the start screen, the measuring display used last time appears.



▪ 3.2 Brightness of display

Increase the picture brightness with  and decrease it with .

▪ 3.3 Beeper



With  +  the beeper toggles on and off.


▪ 3.4 Status line

In the lower display area the status line is located with time, date, beeper on or off, battery condition and power supply signal, as well as on the left side the number of the current measuring display.

UC 660 Mobil Version 1.6.x

- 3.5 Selection of the measuring display


Select the measuring display with  and , the number of the current display is shown at the bottom left within the status line, here it is number 2:



There are 10 measuring displays. Within the measuring displays there are measuring windows. The amount and the size of these windows, as well as their settings can be individually fitted. This is described in the chapter “Settings of Measuring windows”. So you can define appropriate Displays for many different measuring tasks. In delivery status, different measuring displays are already preset.


The warning signs inside the Measuring windows indicate, that the zero point of the appropriate channel is not adjusted yet, read more about that in chapter “Zero point correction”.


- 3.6 Reset of peak values


With  the minimum and maximum values are reset.

UC 660 Mobil Version 1.6.x



- 3.7 Display hold

Press  „HOLD“ for holding the display (freeze).








This state can ONLY be left with  „GO“.

- 3.8 Methods of input

Most settings are done with the keys  ⁴ and  ⁶ .

These keys are featured with automatic repeat. For that, just hold the keys.

At some settings, numerical values are keyed in directly. This is done by holding the  -key and the number keys  ⁰ to  ⁹ , the decimal point key  [.] , as well as the sign key  [#] .



This method is called “numerical” in the following of this manual.



- 3.9 Switch off

With  the device shuts down.



▪ 4. Setting sensor parameters



With  enter the Sensor parameter settings:

CH1 Setup	Serial Number:				
Signal: 4..20 mA	?				
Mode: Pressure ↓↓↓	?				
Unit: bar	?				
Range: 0,000	?				
Range: 600,00	?				
Impulse: 1,000	?				
01.01.2017 16:14:35  					
CH 1	CH 2	CH 3	CH 4	CH 5	CH 6



Select the channel to be adjusted with  „CH1“ to  „CH6“.

▪ 4.1 Setting sensor parameters manually

Select the parameter to be adjusted with  and .


The settings for Signal, mode and physical unit are changed with  and .



The numerals of the start value, the end value and the pulses(k-factor) are entered numerical.


The start and end value can also be selected from a list by  and .




UC 660 Mobil Version 1.6.x


- 4.2 Setting sensor parameters by chip identification

Press  for scanning the sensor. If the connected sensor is provided with an identification chip, its parameters will appear in the right column.


CH2 Setup	Serial Number: 00000567111				
Signal: 	4..20 mA				
Mode: Flow	Pressure 				
Unit: l/min	bar				
Range: 0,0000	0,0000				
Range: 10,000	400,00				
Impulse: 1,0000	1,0000				
01.01.2017 16:15:24 					
CH 1	CH 2	CH 3	CH 4	CH 5	CH 6


To take over these parameters press .



CH2 Setup	Serial Number: 00000567111				
Signal: 4..20 mA	4..20 mA				
Mode: Pressure 	Pressure 				
Unit: bar	bar				
Range: 0,0000	0,0000				
Range: 400,00	400,00				
Impulse: 1,0000	1,0000				
01.01.2017 16:16:12 					
CH 1	CH 2	CH 3	CH 4	CH 5	CH 6

With  save the changes and exit this display.

▪ 5. System settings



With  enter the system settings:



Select the parameter to be adjusted with  and .

The time and date are entered numerically.


The time has to be entered in the format HH:MM:SS and the date in the format DD:MM:YY without century.

The other parameters are changed with  and .


The measuring speed determines the speed of the numerical and the graphical display. The slower the measuring speed, the slower the sampling rate. This setting affects also the recording time at the PC program.

The digital filter determines the inertia of the numerical display. The higher the filter, the higher the inertia of the display.




The rounding specifies, how many digits shall be cut after decimal point.

With  save the changes and exit this display.

▪ 6. Zero point correction

With  enter the zero point correction.



With  „CH1“ to  „CH6“ the zero point correction will be performed for the appropriate channel. With  start an automatic sequence for all six channels.




UC 660 Mobil Version 1.6.x


Attention: Deviation greater than +/- 3% will not be accepted.
With a faultless sensor without loading the zero point will be calibrated and the OK sign appears.






Attention: At channels which are set to frequency input there is no zero point correction, because frequency is absolute.

With  save the changes and exit this display.

▪ 7. Memory functions

With  „MEMO“ enter the memory functions:



Select the memory page with  and , or enter the number of the page numerically.





Occupied memory pages are marked with a small quadrat.

For every occupied memory page the recording parameters, date and time of recording, as well as a short description, if inserted at the recording, are shown.

For a occupied memory page the recording parameters are not changeable.


- 7.1 Record a measurement

Select an empty memory page.

The recording parameters are selected with  and  and are changed with  and .

- 7.1.1 Automatic triggering



For automatic triggering first select the channel to be triggered on.

For triggering on a difference press the key  „DIFF“ several times for the desired difference channel.

Attention: Only channels with the same physical mode and unit can be selected for difference triggering.

Then select a trigger mode. The first symbol marks the start condition, the second symbol the stop condition for the recording.

The triggering is edge controlled.

After that enter a trigger level either with  and  in 5% steps, or directly numerical a level between 0 and 100%.

The calculated trigger value is shown below.

- 7.1.2 Manual triggering

For manual triggering select trigger mode “HAND”, the recording will then be started with pressing a key. The parameters trigger channel and trigger level are not considered at this case.


UC 660 Mobil Version 1.6.x

7.1.3 Recording time





Select a recording time which is as near as possible at the current expected measuring time to get the maximum degree of resolution.


7.1.4 Short description of a recording


The date and time of a recording are generally stored. For a better assignment, here is a possibility for adding a short description with 2x20 characters to the intended recording.


For that press .



With , , ,  select the character, short press for single step, otherwise hold the key.

With  the character is set,

with , „<-“ the last character is deleted.


After completed exit this display with .

UC 660 Mobil Version 1.6.x

- 7.1.5 Initiate a recording

The following example shows the settings for automatic triggering on channel 2, recording start with rising edge, recording stop with falling edge, trigger level at 10%, 60,00 bar at this case, recording time 5 minutes and the short description "MOTOR X1":




With  „STRT“, the recording is initiated, here with automatic triggering...



...and here with manual triggering:





The device is now waiting for the preset trigger conditions. During that, a trigger advance up to 10% of the total recording time will be recorded.

This status can ONLY be exited with  „STOP”.

UC 660 Mobil Version 1.6.x


7.1.6 Start the recording

The recording starts with automatic triggering as soon as the trigger level is reached, or with manual triggering by pressing  „TRIG“.



7.1.7 Stop the recording

The end of a recording can be reached by different kinds:


1. You press  „STOP“
2. A preset trigger condition for stopping the recording occurs
3. The preset recording time has elapsed
4. With battery operation, when the battery runs low


After the recording has finished, the normal measuring display appears again.


UC 660 Mobil Version 1.6.x

- 7.2 Invoke stored recordings



Select an occupied memory page





With  „SHOW“, this page is invoked




UC 660 Mobil Version 1.6.x


There is a fine dotted measuring line which can be moved with  and . For fast moves, hold the appropriate key, for slow moves press the key short time. The values measured at the position of the measuring line are shown in the left measuring windows.


The second, rough dotted line is the reference line. With  „] [„, the lines can be swapped. In this way, an area can be located with the two lines.





The selected area can be magnified with  „<+>“ . This procedure can be repeated until the maximum resolution of the measured curve is reached.

The measuring window below shows the time difference (dt) between the measuring and the reference line. This time is formatted automatically from 0h00'00 to 0'00.000 adapt to the resolution.




With , „>--<“, scale down to the 100% total view.

With , close the memory page.


With , exit the memory function display.

▪ 8. Status key, show device information


With  „STAT“ enter the status display:





The OK signs indicate everything is faultless, the device is ready for use.
Warning signs indicate a fault, the proper function cannot be ensured any more.
This example shows the failure of the sensor supply, see more information about that in the chapter “Error messages”.

With  exit this display.

▪ 9. Info key, show all sensor information


With  get the information about the sensor settings for all channels:




With  exit this display.

▪ 10. Battery indicator


The battery indicator shows the battery condition as follows:



 The battery is running low, the charger must be connected


 The battery is charging


 The battery is fully charged, no charging anymore

▪ 11. Scanning a sensor with identification chip

With  enter the sensor scan display. This scanning is only for your information, the values can only be taken over within the sensor parameter settings.


With  „CH1“ to  „CH6“ select the Channel to be scanned. If the connected sensor is provided with an identification chip, its parameters will appear immediately.






With  exit this display.

▪ 12. Configuration of measuring displays

The 10 measuring displays are preset in delivery status, you can adapt these for your measuring tasks.


For that press , the first measuring window is marked.


With  and  select the window to be adjusted.



UC 660 Mobil Version 1.6.x


- 12.1 Delete measuring windows

With  delete the marked window.



Then select the next window and delete it too.

This way you can delete all not used or all windows.




UC 660 Mobil Version 1.6.x


- 12.2 Set measuring windows

With every keypress on **SET** a new, bigger measuring window appears, as long as it finds a place. With **CR** this window will be fixed. For more windows, repeat this procedure. Here you also can delete windows as well.

Example 1, numerical:




Example 2, graphical:





UC 660 Mobil Version 1.6.x

12.3 Configure measuring windows

select the window to be configured.

With  „CH „, select the channel to be displayed.


With  „MODE“ select the display mode:
„AKT“ for the current value
„MIN“ for the stored minimum value
„MAX“ for the stored maximum value

With  „DIFF“ select a channel for differential measuring.


Attention: Only channels with the same physical mode and unit can be selected for differential measuring.


The following example shows the configurations

- at position 1 the channel 1, current measuring value,
- at position 2 the channel 2, current measuring value,
- at position 3 the difference between channel 1 and channel 2, current value,
- at position 4 the difference between channel 1 and channel 2, minimum value,
- at position 5 the difference between channel 1 and channel 2, maximum value:





UC 660 Mobil Version 1.6.x

With  „SCAL“ change the scale for the GRAPHICAL display of the marked window. All measuring windows can be scaled individually.




By default, the scaling is set to the start and end values of the appropriate sensor. You can enter a lower and upper tolerance value, achieving a greater magnification within the tolerance area and a graphical control of tolerance deviation.


With  and  select the start or end value and enter it numerically.

With  save the changes and exit this display.


If necessary, scale the other measuring windows in the same manner.


UC 660 Mobil Version 1.6.x


When all adjustments are done, exit the configuration with .




13. Colour profiles

With  enter the colour profile settings:



There are 6 colour profiles which can be rotated with .

The factory profiles Factory 1 to Factory 3 are unchangeable preset, the user profiles User 1 to User 3 can be changed.



UC 660 Mobil Version 1.6.x

Press



for the background colour of the measuring display



for the background colour of the measuring windows







for the background colour of the marked measuring window




for the font colour of the values




for the font colour of the labels

All colours are adjusted with the RGB rulers, with ⁸ and ² select the ruler, with ⁴ and ⁶ change the value.

With ⁰ save the changes and exit this display.


▪ 14. Error messages


With malfunctions, error messages can appear, like this on for example:



This error occurs from a short-circuited measuring line. Solve this problem by replacing the measuring line and the fuse “F2 SENSOR” at the left top of the device. Then the error message will disappear automatically. Spare fuses are in the case of the device.

For all other error messages please contact us.


With  error messages can be ignored and faded out. Measurements are not possible at this point, but you could invoke memory pages for example. As hint on the error a warning sign persists right below.

You can see the kind of error in the status display with  „STAT“ .


▪ 15. Reset the device

If necessary due to a malfunction to reset the device,


keep holding **ON** until the restart occurs. This takes about 10 seconds.




Select your language with **F2** „DT“ Deutsch or with **F5** „EN“ English.
After that two options for reset appear.



UC 660 Mobil Version 1.6.x



With  „KONF“ all user settings are restored.

With  „FACT“ delivery status, all user settings are deleted

If the malfunction still exists after restoring the user settings, repeat the reset and select delivery status.

If the device reset does not behave as described, or no restart occurs after 15 seconds, repeat the procedure with connected mains adaptor.



If this also has no success, the firmware must be transferred by means of the PC program “VisUC660”

For that keep holding  and  together until the boot loader appears. Read on now in the chapter “Firmware-Update”.

▪ 16. Firmware-Update


For the firmware update absolutely connect the mains adaptor!

First disconnect the USB connection.

With  +  invoke the boot loader, which is used to restore the firmware of the device via the PC-Program "VisUC660".

If this way is not possible due to a malfunction,


keep holding  and  together, until the boot loader appears.



If you do not want to update the firmware, then exit the boot loader with .

The device will be reset, more information about that in the chapter "Reset the device".

Now connect the USB connection and start the update on the PC.



Wait until the restart occurs.

Meanwhile DO NOT switch off the device!

After the restart, the device will be reset, see chapter "Reset the device".

Disconnect the USB connection.

▪ 17. Technical specifications

▪ Connections

6 Inputs analogue	0/4...20 mA
therefrom 3 switchable to frequency input	1 Hz ... 12 KHz / max. 35V
1 USB-connection	USB 2.0
1 Connection for mains adaptor	10 – 30 V / 2,5 A

▪ Built-in battery

Technology	NiMh
Capacity	10Ah
Battery running time at 20°C, Medium brightness and 3 Sensors:	ca. 12 hours

▪ Screen

Colour display fully sunlight capable	5,7" VGA
Backlight with long life LED	50000 hours
Custom specific start screen on request	

▪ Measuring converter

Resolution	24 Bits
Sampling rate	0,33 ms per channel
Accuracy	< +/- 0, 15%

▪ Measuring data memory

Memory pages	100
Recording time	30 s ... 24h

▪ Operating conditions

Temperature	-10°C ... +70°C
Humidity relative	20 ... 80 %

▪ General

Dimensions	ca. W220xH260xD60
------------	-------------------

▪ Measuring lines

The measuring lines consist of PUR, signal colour yellow, oil resistant and drag chain capable, high grade connectors from the medical engineering.